














NEEDLE VALVES			LEVER TAPS																																												
<p><u>No. N.V.P.40</u> <u>BARB NEEDLE</u> <u>VALVE 90°</u></p>  <table border="1"> <thead> <tr> <th>PART No</th> <th>HOSE</th> <th>BSP</th> </tr> </thead> <tbody> <tr> <td>04NVP400302</td> <td>3/16</td> <td>1/8</td> </tr> <tr> <td>04NVP400402</td> <td>1/4</td> <td>1/8</td> </tr> <tr> <td>04NVP400502</td> <td>5/16</td> <td>1/8</td> </tr> <tr> <td>04NVP400504</td> <td>5/16</td> <td>1/4</td> </tr> <tr> <td>04NVP400604</td> <td>3/8</td> <td>1/4</td> </tr> </tbody> </table>			PART No	HOSE	BSP	04NVP400302	3/16	1/8	04NVP400402	1/4	1/8	04NVP400502	5/16	1/8	04NVP400504	5/16	1/4	04NVP400604	3/8	1/4	<p><u>No. N.V.105</u> <u>MALE BSP NEEDLE</u> <u>VALVE</u></p>  <table border="1"> <thead> <tr> <th>PART No</th> <th colspan="2">BSP</th> </tr> </thead> <tbody> <tr> <td>04NV10502</td> <td>1/8</td> <td></td> </tr> <tr> <td>04NV10504</td> <td>1/4</td> <td></td> </tr> </tbody> </table>			PART No	BSP		04NV10502	1/8		04NV10504	1/4		<p><u>No. DB1 BENT</u> <u>DRAIN COCK</u></p>  <table border="1"> <thead> <tr> <th>PART No</th> <th colspan="2">BSP</th> </tr> </thead> <tbody> <tr> <td>04DB102</td> <td>1/8</td> <td></td> </tr> <tr> <td>04DB104</td> <td>1/4</td> <td></td> </tr> <tr> <td>04DB106</td> <td>3/8</td> <td></td> </tr> </tbody> </table>			PART No	BSP		04DB102	1/8		04DB104	1/4		04DB106	3/8	
PART No	HOSE	BSP																																													
04NVP400302	3/16	1/8																																													
04NVP400402	1/4	1/8																																													
04NVP400502	5/16	1/8																																													
04NVP400504	5/16	1/4																																													
04NVP400604	3/8	1/4																																													
PART No	BSP																																														
04NV10502	1/8																																														
04NV10504	1/4																																														
PART No	BSP																																														
04DB102	1/8																																														
04DB104	1/4																																														
04DB106	3/8																																														
<p><u>No. N.V.P.42</u> <u>BARB NEEDLE</u> <u>VALVE</u></p>  <table border="1"> <thead> <tr> <th>PART No</th> <th>HOSE</th> <th>BSP</th> </tr> </thead> <tbody> <tr> <td>04NVP420302</td> <td>3/16</td> <td>1/8</td> </tr> <tr> <td>04NVP420402</td> <td>1/4</td> <td>1/8</td> </tr> <tr> <td>04NVP420502</td> <td>5/16</td> <td>1/8</td> </tr> <tr> <td>04NVP420504</td> <td>5/16</td> <td>1/4</td> </tr> <tr> <td>04NVP420604</td> <td>3/8</td> <td>1/4</td> </tr> </tbody> </table>			PART No	HOSE	BSP	04NVP420302	3/16	1/8	04NVP420402	1/4	1/8	04NVP420502	5/16	1/8	04NVP420504	5/16	1/4	04NVP420604	3/8	1/4	<p><u>No. N.V.808 x 1/8</u> <u>No. N.V.404 x 1/4</u> <u>M/F NEEDLE</u> <u>VALVES</u></p>  <table border="1"> <thead> <tr> <th>PART No</th> <th colspan="2">BSP</th> </tr> </thead> <tbody> <tr> <td>04NV80802</td> <td>1/8</td> <td></td> </tr> <tr> <td>04NV40404</td> <td>1/4</td> <td></td> </tr> </tbody> </table>			PART No	BSP		04NV80802	1/8		04NV40404	1/4		<p><u>No. DT3 DRAIN</u> <u>COCK</u></p>  <table border="1"> <thead> <tr> <th>PART No</th> <th colspan="2">BSP</th> </tr> </thead> <tbody> <tr> <td>04DT302</td> <td>1/8</td> <td></td> </tr> <tr> <td>04DT304</td> <td>1/4</td> <td></td> </tr> </tbody> </table>			PART No	BSP		04DT302	1/8		04DT304	1/4				
PART No	HOSE	BSP																																													
04NVP420302	3/16	1/8																																													
04NVP420402	1/4	1/8																																													
04NVP420502	5/16	1/8																																													
04NVP420504	5/16	1/4																																													
04NVP420604	3/8	1/4																																													
PART No	BSP																																														
04NV80802	1/8																																														
04NV40404	1/4																																														
PART No	BSP																																														
04DT302	1/8																																														
04DT304	1/4																																														
<p><u>No. N.V.104</u> <u>FEMALE BSP</u> <u>NEEDLE VALVE</u></p>  <table border="1"> <thead> <tr> <th>PART No</th> <th colspan="2">BSP</th> </tr> </thead> <tbody> <tr> <td>04NV10402</td> <td>1/8</td> <td></td> </tr> <tr> <td>04NV10404</td> <td>1/4</td> <td></td> </tr> </tbody> </table>			PART No	BSP		04NV10402	1/8		04NV10404	1/4		<p><u>No. N.V.50A</u> <u>MALE BSP NEEDLE</u> <u>VALVE 90°</u></p>  <table border="1"> <thead> <tr> <th>PART No</th> <th>BSP</th> <th>BSP</th> </tr> </thead> <tbody> <tr> <td>04NVA500202</td> <td>1/8</td> <td>1/8</td> </tr> <tr> <td>04NVA500402</td> <td>1/4</td> <td>1/8</td> </tr> <tr> <td>04NVA500404</td> <td>1/4</td> <td>1/4</td> </tr> </tbody> </table>			PART No	BSP	BSP	04NVA500202	1/8	1/8	04NVA500402	1/4	1/8	04NVA500404	1/4	1/4	<p><u>No. JT3 BARBED</u> <u>LEVER TAP</u></p>  <table border="1"> <thead> <tr> <th>PART No</th> <th>HOSE</th> <th>BSP</th> </tr> </thead> <tbody> <tr> <td>04JT30302</td> <td>3/16</td> <td>1/8</td> </tr> <tr> <td>04JT30402</td> <td>1/4</td> <td>1/8</td> </tr> <tr> <td>04JT30502</td> <td>5/16</td> <td>1/8</td> </tr> <tr> <td>04JT30602</td> <td>3/8</td> <td>1/8</td> </tr> </tbody> </table>			PART No	HOSE	BSP	04JT30302	3/16	1/8	04JT30402	1/4	1/8	04JT30502	5/16	1/8	04JT30602	3/8	1/8			
PART No	BSP																																														
04NV10402	1/8																																														
04NV10404	1/4																																														
PART No	BSP	BSP																																													
04NVA500202	1/8	1/8																																													
04NVA500402	1/4	1/8																																													
04NVA500404	1/4	1/4																																													
PART No	HOSE	BSP																																													
04JT30302	3/16	1/8																																													
04JT30402	1/4	1/8																																													
04JT30502	5/16	1/8																																													
04JT30602	3/8	1/8																																													
			<p><u>No. 104 FEMALE</u> <u>LEVER TAP</u></p>  <table border="1"> <thead> <tr> <th>PART No</th> <th colspan="2">BSP</th> </tr> </thead> <tbody> <tr> <td>04L10402</td> <td>1/8</td> <td></td> </tr> <tr> <td>04L10404</td> <td>1/4</td> <td></td> </tr> </tbody> </table>			PART No	BSP		04L10402	1/8		04L10404	1/4																																		
PART No	BSP																																														
04L10402	1/8																																														
04L10404	1/4																																														
			<p><u>No. 808 x 1/8</u> <u>No. 404 x 1/4</u> <u>M/F LEVER TAPS</u></p>  <table border="1"> <thead> <tr> <th>PART No</th> <th colspan="2">BSP</th> </tr> </thead> <tbody> <tr> <td>04L80802</td> <td>1/8</td> <td></td> </tr> <tr> <td>04L40404</td> <td>1/4</td> <td></td> </tr> </tbody> </table>			PART No	BSP		04L80802	1/8		04L40404	1/4																																		
PART No	BSP																																														
04L80802	1/8																																														
04L40404	1/4																																														

COMPRESSOR VALVES			90° NON RETURN VALVE																				
<p><u>No. 108 NON RETURN</u> <u>VALVE</u></p>  <table border="1"> <thead> <tr> <th>PART No</th> <th>TUBE</th> <th>BSP</th> </tr> </thead> <tbody> <tr> <td>04NRV108</td> <td>1/2</td> <td>1/2</td> </tr> </tbody> </table>			PART No	TUBE	BSP	04NRV108	1/2	1/2	<p><u>90° NON RETURN</u> <u>VALVE</u></p>  <table border="1"> <thead> <tr> <th>PART No</th> <th>INLET</th> <th>OUTLET</th> </tr> </thead> <tbody> <tr> <td>04NRV90-08</td> <td>1/2 bsp Flare</td> <td>1/2 bsp Male</td> </tr> <tr> <td>04NRV90-0812</td> <td>1/2 bsp Flat</td> <td>3/4 bsp Male</td> </tr> <tr> <td>04NRV90-12</td> <td>3/4 bsp Flare</td> <td>3/4 bsp Male</td> </tr> </tbody> </table>			PART No	INLET	OUTLET	04NRV90-08	1/2 bsp Flare	1/2 bsp Male	04NRV90-0812	1/2 bsp Flat	3/4 bsp Male	04NRV90-12	3/4 bsp Flare	3/4 bsp Male
PART No	TUBE	BSP																					
04NRV108	1/2	1/2																					
PART No	INLET	OUTLET																					
04NRV90-08	1/2 bsp Flare	1/2 bsp Male																					
04NRV90-0812	1/2 bsp Flat	3/4 bsp Male																					
04NRV90-12	3/4 bsp Flare	3/4 bsp Male																					