

45° INVERTED FLARE

IFS

FITTINGS

CATEGORY 1

No.58 BRASS INVERTED FLARE NUT



PART No	TUBE
0158-02	1/8
0158-03	3/16
0158-04	1/4
0158-05	5/16
0158-06	3/8
0158-08	1/2

No 59 45deg INVERTED FLARE ELBOW



PART No	TUBE		NPT
015945-0302	3/16	x	1/8
015945-0402	1/4	x	1/8
015945-0502	5/16	x	1/8
015945-0604	3/8	x	1/4

No 62W INVERTED FLARE SINGLE UNION



With washer face


PART No	TUBE		MALE
0162W-0306	3/16	x	3/8-24tpi
0162W-0307	3/16	x	7/16-20tpi
0162W-0310M	3/16	x	10mmx1mm

No 58S STEEL INVERTED FLARE NUT



PART No	TUBE
0158S-03	3/16
0158SR-03	3/16-10mm x 1mm
0158S-04	1/4
0158S-05	5/16
0158S-06	3/8
0158S-08	1/2

No 61 INVERTED FLARE TEE



PART No	TUBE
0161-03	3/16
0161BR-03	3/16 Bracketed
0161-04	1/4
0161-05	5/16
0161-06	3/8

No 63 INVERTED FLARE JOINER



PART No	TUBE
0163-02	1/8
0163-03	3/16
0163-04	1/4
0163-05	5/16
0163-06	3/8
0163-08	1/2

No 58SL STEEL LONG INVERTED FLARE NUT



PART No	TUBE
0158SL-03	3/16
0158SLR-03	3/16-10mm x 1mm
0158SL-04	1/4

No 62 INVERTED FLARE MALE UNION



PART No	TUBE		NPT
0162-0202	1/8	x	1/8
0162-0302	3/16	x	1/8
0162-0402	1/4	x	1/8
0162-0404	1/4	x	1/4
0162-0502	5/16	x	1/8
0162-0504	5/16	x	1/4
0162-0602	3/8	x	1/8
0162-0604	3/8	x	1/4
0162-0606	3/8	x	3/8
0162-0806	1/2	x	3/8


No 59 INVERTED FLARE ELBOW



PART No	TUBE		NPT
0159-0202	1/8	x	1/8
0159-0302	3/16	x	1/8
0159-0402	1/4	x	1/8
0159-0404	1/4	x	1/4
0159-0502	5/16	x	1/8
0159-0504	5/16	x	1/4
0159-0602	3/8	x	1/8
0159-0604	3/8	x	1/4
0159-0606	3/8	x	3/8
0159-0806	1/2	x	3/8

ADAPTORS

No 66 H/BARB x INVERTED FLARE



PART No	HOSE		TUBE
0166-0504	5/16	x	1/4
0166-0505	5/16	x	5/16
0166-0506	5/16	x	3/8
0166-0605	3/8	x	5/16
0166-0606	3/8	x	3/8

No 67 H/BARB x INVERTED FLARE ELBOW



PART No	HOSE		TUBE
0167-0404	1/4	x	1/4
0167-0405	1/4	x	5/16
0167-0505	5/16	x	5/16
0167-0605	3/8	x	5/16
0167-0606	3/8	x	3/8

No 68 MALE BSP x MALE INVERTED FLARE ADAPTOR



PART No	TUBE		BSP
0168-0302	3/16	x	1/8
0168-0402	1/4	x	1/8
0168-0504	5/16	x	1/4
0168-0604	3/8	x	1/4

For tube cutting tools see page 130

